



How to fit Pro-Bolt Quick Release Fasteners

The first thing about the QR set up is that there isn't one specific way to assemble them, it really depends on personal preference and application.

There are 4 main ancillary items that are supplied with quick release.

- Plastic Cup Washer
- Metal Spring
- Plastic Flat Washer
- Metal 'Grippa' washer



For the first part of assembly there are 2 options.

You can either fit the Cup Washer and Spring to the fastener, which is used to create tension between the fastener and receptacle once assembled.



Or you can fit the flat washer.



Once this has been chosen you can put the fastener through the fairing.



How to fit Pro-Bolt Quick Release Fasteners



Depending on the application and personal preference, you now have the option to add the 'Grippa' washer to the fastener at the back of the fairing.

In the unlikely event of the quick release fastener vibrating loose from the receptacle, it will prevent them from falling back out the fairing.

This can be used regardless of your previous washer selection.



Once you are at this stage you can now fit them to the receptacles that are on the bike. Hopefully this makes the washer assembly a bit more clear for you.

With regards to the receptacle, I am not able to give you exact instructions as to how to fit them. There are 2 main types that we use for these quick release, either Slide-On (CLIP3) or Rivet-On (CLIP6).

It varies from model to model, and really you need to mimic what the manufacturer does as standard.

To view a 'How To' video, please click [here](#).